
STRUCTURAL NOTES

- 1. ALL DIMENSIONS ARE TO BE VERIFIED BY THE CONTRACTOR PRIOR TO FABRICATION/CONSTRUCTION.
- 2. FRAMING LUMBER TO BE PRESSURE TREATED DOUGLAS FIR NO. 1 OR BETTER.
- 3. PLYWOOD SHALL BE PER AMERICAN PLYWOOD ASSOCIATION SPECIFICATIONS.
- 4. ALL FRAMING DEVICES ARE SIMPSON "STRONG-TIE" CONNECTIONS. INSTALL DEVICES AND FILL ALL NAIL HOLES PER MANUFACTURER'S LITERATURE/SPECIFICATIONS.
- 5. ALL NAILS SHALL BE COMMON. FOR NAILING NOT NOTED REFER TO IBC TABLE 2304.9.1. ALL NAILS INTO PRESSURE TREATED WOOD TO BE HOT DIPPED GALVANIZED.
- 6. FOR FRAMING DETAILS NOT SHOWN REFER TO IBC "CONVENTIONAL FRAMING" PROVISIONS.
- 7. MEMBERS IN CONTACT WITH CONCRETE OR MASONRY SHALL BE PRESSURE TREATED OR FOUNDATION GRADE REDWOOD. DO NOT PLACE ANY WOOD MEMBERS IN CONTACT WITH THE EARTH.
- 8. PLYWOOD SHEAR WALL PANEL VENEERS SHALL NOT BE BROKEN OR CRUSHED UPON THE INSTALLATION OF SHEAR WALL NAILING.
- 9. SHEATHING TO CLEAR ALL CONCRETE SURFACES BY A MINIMUM OF 1".
- 10. SIDE SHEATHING TO ANCHOR TO EXISTING WALL AT UPPER LEDGER AND LOWER NAILER.

MAINTENANCE NOTE:

A SNOW SHED WILL HELP PREVENT SNOW AND ICE ACCUMULATION, BUT IS NOT A SUBSTITUTE FOR THE UPKEEP AND MAINTENCE OF THE ADJOINING RESIDENCE OR STRUCTURE. IT IS IMPORTANT TO KEEP GUTTERS FREE OF LEAVES AND DEBRIS, INCLUDING THOSE ABOVE OR NEAR THE NATURAL GAS METER. ALSO, NO SHED WILL PROTECT AGAINST FALLING ICE SHEETS, SO CARE MUST BE TAKEN TO PREVENT THE ACCUMULATION OF ICE THAT COULD RESULT IN AN ICE FALL.






GABLE ROOF - TYPICAL PLAN VIEW

SCALE: 1/2" = 1'-0"

GAS METER SHELTER IMPROVEMENT PLANS GABLE-PLAN VIEW




650 PSF GABLE ROOF - SIDE VIEW

SCALE: 1/2" = 1'-0"

GAS METER SHELTER
IMPROVEMENT PLANS
650 PSF GABLE - SIDE VIEW

SCO

690-272-8841 BRO-272-8841 RR-474E BRO-582-4043 FAX: BRO-285-8738



650 PSF GABLE ROOF - FRONT VIEW

SCALE: 1/2" = 1'-0"

GAS METER SHELTER
IMPROVEMENT PLANS
650 PSF GABLE - FRONT VIEW